

Siser Materials That Can be Applied with a Household Iron



Adheres to:
100% cotton, 100% polyester,
poly/cotton blends, leather
Peel HOT or COLD



Adheres to:
100% cotton, 100% polyester,
poly/cotton blends, leather
Peel HOT or COLD




Adheres to:
100% cotton, 100% polyester,
poly/cotton blends, leather, nylon
Peel HOT or COLD



Adheres to: 100% cotton,
100% polyester,
poly/cotton blends
Peel COLD



Adheres to:
100% cotton, leather,
poly/cotton blends, nylon
Peel COLD



Adheres to: 100% cotton,
100% uncoated polyester,
poly/cotton blends
Peel COLD



Adheres to: 100% cotton,
100% polyester,
poly/cotton blends
Peel WARM



Adheres to: 100% cotton,
100% polyester,
poly/cotton blends
Peel COLD

Before Application

Preheat iron to cotton setting ° Place fabric for heat application on a firm surface (such as a cutting board) ° Preheat garment for 2-3 seconds

Weeding and Application



1 Cut in reverse



2 Weed (pick)



3 Place transfer on the garment as desired



4 Cover with a cover sheet



5 Use FIRM pressure for 10 seconds
Cover entire image. Do not slide iron



6 Remove the clear carrier



7 Cover and reheat for another
5-10 seconds



8 Wait at least 24 hours
before first wash

RECOMMENDED ACCESSORIES

Siser weeder
Multipurpose paper
Heat transfer cover sheet
Heat Transfer Pillow

WASHING INSTRUCTIONS

Machine wash WARM or HOT with mild detergent
Wait 24 hours before first wash

